



## CHAMBER COOLING PROBLEM

Check to verify that the screen is displaying “COOLING”, indicating that Chamber is in a “COOLING CYCLE” and that the word “HEAT” is not on the display.

If the Chamber is in a Cooling Cycle and it will not cool down, then the most likely problem is it has lost its refrigerant.

Have a Refrigeration Service Technician check the Refrigeration Charge.

Refrigeration Specifications : **Type R-134A** (The type of refrigerant used will be marked on the top of the compressor.)

After finding and repairing and leak(s), the system should be charged in **Liquid Form** at **40 lbs. Pressure on the Low Side**. Whoever charges the system can follow their pressure / temperature chart.

Note : The High Pressure Side will take care of itself when filled this way.

***Innovative Design, Engineering and Manufacturing since 1946***

4420 San Fernando Road Glendale CA 91204 818 247 7500 fax 818 247 7257 melco@melcowire.com www.melcowire.com